

CROSSRC V3.0 Servo proteceter


Features: the servo works in full stroke without adjusting. The servo only generates working current during gear shifting and differential lock turn on. The relatively large load current will not be generated after shifting or differential lock on, which can effectively prevent the damage of the servo.

The key points of installation to gearshift and differential lock servo:

1. The servo needs to be medium-sized (22 ~ 25g), and the working angle of the servo is 90 degrees. The 90 degrees refers to the angle of the servo from the leftmost side to the rightmost side. Generally, the default working angle of the servo is 90 degrees.


2. Before installation, connect the servo with the remote control equipment, and power on the servo to return to the center.

Drawing 1



Gearshift servo installation


Drawing 2






a、Fix the required accessories as shown in Drawing 2. Turn the remote shift control switch to the low gear position.

b、Hook the shift spring 44172 into the hole of the transmission shift lever. Then install the servo disc on the servo with the shift tension spring 44172 in a natural non tensile state.

Drawing 3



c、Tighten the 11227 servo plate compression screw under the power off. The power on test is successful, the gearshift servo installation is completed.

Drawing 1	 41819 91175 11227 12206 11401 M2.5x8 X1 M2 X1 M3x4 X2 91176 X2 42231 X2	Installation of differential lock servo a、Prepare relevant parts as shown in Drawing 1.
Drawing 2		b、Turn on the power supply, turn the switch of the remote controller to the differential lock state for make 41819 is up on. As shown in drawing 2, install the disc on the servo, turn off the power supply, and tighten the compression screw of the servo disc.
Drawing 3		c、Thread the two cables into 41819, and then into 91176 protective tube and 42231 limiter respectively as shown in drawing 3. Naturally straighten the front and rear differential cables (not tensioned), leave a gap of about 1mm, and tighten the meter screw of the limiter. d、Power on and test the differential lock open and lock status. If the differential lock turn on fault, please reduce the 1mm gap in the left figure. If it's locked fault, please check and adjust whether the cable routing is smooth.